

SAMSUNG YP-T5

FM Radio - MP3/WMA Player - Recorder - Data Storage

Built-in Memory capacity

YP-T5 H = 128 MB

YP-T5 V = 256 MB

YP-T5 X = 512 MB

Voltage = 1.5V AAA alkaline

Playing time 12 hours Volume 20

Size=.91x.91x2.13 inches

Weight = .85 ounces no battery

Noise 80dB with 20KHz LPF

Earphones = 5mW each

Frequency = 20Hz - 20KHz

Temperature 23-95 F

FM Frequency - 87.5-108MHz

FM Signal to Noise Ratio 45dB

FM Useable Sensitivity = 10 dB

File Support = MPG 1/2/2.5 Layer3

8 Kbps - 320 Kbps, 8 KHz= 48 KHz

WMA 48 Kbps - 192 Kbps,

8 KHz - 48 KHz

MIC = Microphone

REC = Recording

A - B = Loop Repeating /
Scan for FM stations

▶ || = PLAY/PAUSE

HOLD > = Button Freezer

ENC = Line In jack

USB - micro In/Out port

Equalizer

▶ || ■
Play/Pause/Stop

Bit rate

Play Mode

Menu Mode

Track Number

Size or Time

Track Title

Battery Remaining

JOY stick

Neck strap Hook

Earphone Jack

Battery Sliding-Door

While MP3's are playing: ▶

Poke JOY in - Options menu

Poke JOY up - **Volume up**

Poke JOY down - **Volume down**

Poke JOY left - **Previous MP3**

Poke JOY right - **Next MP3**

Hold JOY in - View MP3 folders

Poke JOY left - **ROOT folders** [if you made them]

Poke JOY down - **Next MP3 folder**

Poke JOY right - **Enters folder**

Poke JOY up/down - **Next MP3**

Poke JOY down - **Play selected MP3**

Poke JOY left - **Back to folder**

OPTIONS MENU

--- Poke JOY up or down - **highlight next option**

Poke JOY in - **select highlighted item**

Settings

File

Poke Joy Up/down - **Highlights item**

Poke Joy right - **Deletes item**

Poke Joy right - **Formats**

Poke Play - **Returns to playing**

[The file operations are better done while connected to a computer. Placing about seven folders within a folder and then about seven MP3's within a folder makes it easy to remember and to navigate your MP3s.]

FM radio

Options while FM is playing

Press A-B - **Scan & store presets**

Poke JOY up - **Volume up**

Poke JOY down - **Volume down**

Poke JOY left - **Previous station**

Poke JOY right - **Next station**

Poke JOY in - **Options Menu**

Poke Pause - **Switches presets to free tuneing**

Now Playing

Poke JOY up - **Changes selection up**

Poke JOY down - **Changes selection down**

Poke JOY left - **Pauses current selection** - poke play

Poke JOY right - **Pauses current selection** - poke play

Poke JOY in - **Pauses current selection** - poke play

Poke Play - **Plays current selection**

Settings Menu

--- Poke JOY up or down - **highlight next option**

Poke JOY in - **select highlighted item**

Play mode

Normal
Repeate one
Repeat all
Shuffle
11 seconds . .

Sound

Surround
TruBass
WOW
Normal
Classic
Jazz
Rock
DBB
User Defined

Display

Scroll
Time view settings
Used Time
Remaining Time
Used Size - Megabytes
Available Size
Backlight
Time on - seconds
LCD Color - green-red-blue
Contrast

Power off

Time - To shutdown - 0-60 seconds
Sleep - off in 30-60-120 minutes

Encoding ENC

Bitrate - 32-128Kbps
Auto-Sync - 2-4 seconds

WOW level

Surround
TruBass
WOW Optimum
Speaker
Headphone
Earphone
Carpack

Default Volume

Confirm
Cancel